

FLY EQUIPMENT LIST			
CODE		P.L	ITEM
A	A	0	Fire Curtain
01	B	24	Main Curtain *Motorized Fly & Draw
02	1	52	NO.1 Border
03	E1	84	NO.1 Electric *Motorized
04	2	125	NO.1 Shell Wall
05	C1	167	NO.1 Shell Ceiling *Motorized
06	3	197	NO.2 Border
07	4	218	NO.1 Wing
08	E2	254	NO.2 Electric *Motorized
09	5	298	NO.2 Shell Wall
10	6	322	Scenery Batten
11	7	337	NO.2 Wing
12	8	352	Scenery Batten
13	C2	383	NO.2 Shell Ceiling *Motorized
14	9	414	NO.3 Border
15	10	440	NO.3 Shell Wall
16	E3	474	NO.3 Electric *Motorized
17	E4	507	NO.4 CYC-Electric *Motorized
18	R	550	NO.4 Shell Ceiling *Motorized
19	11	588	Black Curtain *Manual Fly & Draw
20	12	612	Cyclorama

THE PLAN OF JHIHSHAN HALL STAGE

